



F1	F2	F3	F4	F5	F6
Esc	! 1	" 2	£ 3	\$ 4 €	% 5
	Q	W	E	R	T
⇧	A	S	D	F	G
⇧	Z	X	C	V	B
	⌘	\	{ }	- _	

Qwerty	Num Lock	7 Home ↶	8 ↑	9 PgUp ⌆	*	Scroll Lock
Print Screen	=	4 ↵	5	6 →	/	Pause
⌘	-	1 End ↘	2 ↓	3 PgDn ⌇	+	Alt Gr
PgUp ⌆	Enter ↵	0 Ins	Ins	Bk Sp ←	. Del	PgDn ⌇

F7	F8	F9	F10	F11	F12
^	&	*	()	⌘	⌘
6	7	8	9	0	⌘
Y	U	I	O	P	~ #
H	J	K	L	: ;	⇧
N	M	< ,	> .	@ ' ,	⇧
+	}	?	/	⌘	
=]	/			

Maltron Qwerty Caps Num Shift



English UK

© PCD Maltron Ltd. 2006

02/03/2006

J89 Qwerty Key Layout

