



F1	F2	F3	F4	F5	F6
Esc	! 1	" 2	£ 3	\$ 4	% 5
@	Q	P	Y	C	B
←	A	N	I	S	F
↑	< ,	> .	J	G	⋮ ;
	⌫	\	{ [-	

Caps Lock	Num Lock	7 ↵	8 ↑	9 ⇅	*	Scr Lk
Prt Sc	=	4 ←	5	6 →	/	Pause
	-	1 ↘	2 ↓	3 ⇅	+	Alt Gr
⇅	Enter	0 Ins	Ins	Bk Sp ←	. Del	⇅

F7	F8	F9	F10	F11	F12
^ 6	& 7	* 8	(9) 0	~ ;
V	M	U	Z	L	⊞
D	T	H	O	R	↵
~ #	W	K	-	X	↑
+ =	}]	? /	⌫		

Maltron
 Qwerty
 Caps
 Num
 Scroll



Win/PC
English UK

L89

Maltron