



F1	F2	F3	F4	F5	F6
Esc	! 1	@ 2	# 3	\$ 4	% 5
	Q q	W w	E e	R r	T t
← →	A a	S s	D d	F f	G g
↑	Z z	X x	C c	V v	B b
	⌨	\	{ }	- =	

Caps Lock	Num Lock	7 ↵	8 ↑	9 ⇩	*	Scr Lk
Prt Sc	=	4 ←	5	6 →	/	Pause
⌨	-	1 ↵	2 ↓	3 ⇩	+	Alt Gr
⇩	Enter	0 Ins	Ins	Bk Sp ←	. Del	⇩

F7	F8	F9	F10	F11	F12
^ 6	& 7	* 8	( 9	) 0	~ `
Y y	U u	I i	O o	P p	⌫
H h	J j	K k	L l	: ;	↩
N n	" ' w	< ,	> .	- _	↑
+ =	} ]	? /	⌨		

Maltron
  Qwerty
  Caps
  Num
  Scroll



Win/PC  
English US

L89 Qwerty Maltron