



F1	F2	F3	F4	F5	F6
⏪	⏩	■	⏮	⏭	⏪
~ #	! 1	" 2	£ 3	\$ 4 €	% 5
K56	Q q	W w	E e	R r	T t
Fn	A a	S s	D d	F f	G g
↑	Z ,	X .	C j	V g	B @
	⌘	 \	{ [	- _	

Esc	Num Lock	7 ↵	8 ↑	9 ⌘	/	▲	☰
Caps Lock	=	4 ←	5	6 →	*	◀▶	⌘
Prt Sc	Scr Lk	1 ↵	2 ↓	3 ⌘	-	◀▶	⌘
Pause	Ins	0 Ins	. Del	Enter ↵	+	⊞	Alt Gr

F7 F17	F8 F18	F9 F19	F10 F20	F11 F21	F12 F22
^ 6	& 7 F23	* 8 F24	( 9	) 0	⌘ 
Y v	U m	I u	O z	P l	K14
H d	J t	K h	L o	: ; r	Fn
N ;	M w	< k	> .	@ - x	↑
+ =	} ]	? /	⌘		

Maltron  Qwerty  Caps  Num  Scroll



Win/PC  
English UK

L89P Qwerty Maltron