



F1	F2	F3	F4	F5	F6
⏪	⏩	■	⏮	⏭	⏯
KEY 42	!	@	#	\$	%
	1	2	3	4	5
KEY 56	Q	P	Y	C	B
	q	w	e	r	t
Fn	A	N	I	S	F
	a	s	d	f	g
⏶	<	>	J	G	"
	, z	. x	c	v	' b
	⏪		{	-	
		\	[_	

Esc	Clear	7	8	9	/	▲	☰
		↶	↑	⏶	/	⏪	⏶
Caps Lock	=	4	5	6	*	⏪	⏶
		←		→	*	⏪	⏶
F13	F14	1	2	3	-	⏪	⏶
		↵	↓	⏶	-	⏪	⏶
F15	Help	0	.	Enter	+	⏪	Alt Gr
	F16	Ins	Del	↵	+	⏪	Alt Gr

F7	F8	F9	F10	F11	F12
F17	F18	F19	F20	F21	F22
^	&	*	()	~
6	7 F23	8 F24	9	0	`
V	M	U	Z	L	KEY 14
y	u	i	o	p	
D	T	H	O	R	:
h	j	k	l	;	Fn
:	W	K	<	-	>
; n	m	,	.	X	"
	+ =	}]	? /	⏪	⏶

Maltron
 Qwerty
 Caps
 Num
 Scroll



Apple-Mac
 English US

L89P Maltron Qwerty