



F1	F2	F3	F4	F5	F6
	! 1	@ 2	# 3	\$ 4	% 5
	Q	W	E	R	T
<i>Fn</i>	A	S	D	F	G
	Z	X	C	V	B
		\	{ [- _	

Esc	Num Lock	7	8	9	/		
Caps Lock	=	4	5	6	*		
Prt Sc <i>F13</i>	Scr Lk <i>F14</i>	1	2	3	-		
Pause <i>F15</i>	Ins <i>F16</i>	0	.	Enter	+		Alt Gr

F7	F8	F9	F10	F11	F12
<i>F17</i>	<i>F18</i>	<i>F19</i>	<i>F20</i>	<i>F21</i>	<i>F22</i>
^ 6	& 7 <i>F23</i>	* 8 <i>F24</i>	(9) 0	~ `
Y	U	I	O	P	
H	J	K	L	: ;	<i>Fn</i>
N	M	< ,	> .	" '	
	+ =	}	? /		

Maltron Qwerty Caps Num Scroll



Win/PC
English US

L89P

Qwerty