



F1	F2	F3	F4	F5	F6
!	"	#	¤	%	&
1	2 @	3 £	4 \$	5 €	6
½	Q	P	Y	C	B
§	q	w	e	r	t
>	A	N	I	S	F
<	a	s	d	f	g
↑	; :	: :	J	G	? \
	, z	. x	c	v	+ b
	Ctrl		Alt	-	.

Esc	Num Lock	7 ↖	8 ↑	9 ↗	/	▲
Caps Lock	=	4 ←	5	6 →	*	◀▶
Prt Sc	Scr Lk	1 ↘	2 ↓	3 ↙	-	◀▶
Pause	Ins	0 Ins	' Del	Enter ↵	+	⊞

F7	F8	F9	F10	F11	F12
/	(	)	=	⌘	⌘
7 {	8 [	9 ]	0 }	'	~
V	M μ	U	Z	L	Å
y	u	i	o	p	
D	T	H	O	R	Ä
h	j	k	l	ö	
Ö	W	K	; -	X ?	↑
n	m	,	.	+	
*	Alt Gr		Ctrl		

Maltron
  Qwerty
  Caps
  Num
  Scroll



Win/PC  
Swedish

L90 Maltron Qwerty