



F1	F2	F3	F4	F5	F6
!	"	#	¤	%	&
1	2 @	3 £	4 \$	5 €	6
½ §	Q	W	E	R	T
>   <	A	S	D	F	G
↑	Z	X	C	V	B
	Ctrl	☞	Alt	-	

Esc	Num Lock	7 ↖	8 ↑	9 ↗	/ ▲
Caps Lock	=	4 ←	5	6 →	* ⏪
Prt Sc	Scr Lk	1 ↘	2 ↓	3 ↙	- ⏩
Pause	Ins	0 Ins	, Del	Enter ↵	+ 🔊

F7	F8	F9	F10	F11	F12
/	( )	=	`	^	
7 {	8 [	9 ]	0 }	~	~
Y	U	I	O	P	Å
H	J	K	L	Ö	Ä
N	M	;	:	? \	↑
*	Alt Gr	☞	Ctrl		

Maltron  Qwerty  Caps  Num  Scroll



Win/PC  
Swedish

L90

Qwerty