



F1	F2	F3	F4	F5	F6
! 1	" 2	£ 3	\$ 4 €	% 5	^ 6
~ ;	Q	P	Y	C	B
	A	N	I	S	F
↑	< ,	> .	J	G	? /
	Ctrl		Alt	-	

Esc	Num Lock	7 ↵	8 ↑	9 ⇄	/	▲
Caps Lock	=	4 ←	5	6 →	*	◀▶
Prt Sc	Scr Lk	1 ↵	2 ↓	3 ⇄	-	◀▶
Pause	Ins	0 Ins	. Del	Enter ↵	+	⊘

F7	F8	F9	F10	F11	F12
& 7	* 8	(9) 0	{ [}]
V	M	U	Z	L	~ #
D	T	H	O	R	@ ' ,
:	W	K	-	X	↑
	+	Alt Gr		Ctrl	

Maltron
 Qwerty
 Caps
 Num
 Scroll



Win/PC
English UK

L90

Maltron