



F1	F2	F3	F4	F5	F6
!	"	£	\$	%	^
1	2	3	4 €	5	6
~	Q	W	E	R	T
`	q	w	e	r	t
	A	S	D	F	G
\	a	s	d	f	g
↑	Z	X	C	V	B
	,	.	j	k	/
	Ctrl	Alt	-		

Esc	Num Lock	7	8	9	/	▲
		↵	↑	⇅	/	▲
Caps Lock	=	4	5	6	*	◀▶
		←	→	→	*	◀▶
Prt Sc	Scr Lk	1	2	3	-	◀▶
		⏎	↓	⇅	-	◀▶
Pause	Ins	0	.	Enter	+	⊞
		Ins	Del	↵	+	⊞

F7	F8	F9	F10	F11	F12
&	*	(	)	{	}
7	8	9	0	[	]
Y	U	I	O	P	~
y	u	i	o	p	~
H	J	K	L	:	@
h	j	k	l	:	@
N	M	<	>	?	↑
n	m	<	>	?	↑
+	Alt Gr	⇧	Ctrl		

Maltron  Qwerty  Caps  Num  Scroll



Win/PC  
English UK

L90 Qwerty Maltron