



F1	F2	F3	F4	F5	F6
! 1	" 2	£ 3	\$ 4 €	% 5	^ 6
~ ;	Q	W	E	R	T
\	A	S	D	F	G
↑	Z	X	C	V	B
	Ctrl	⌘	Alt	-	

Esc	Num Lock	7 ↵	8 ↑	9 ⇅	/	▲
Caps Lock	=	4 ←	5	6 →	*	◀▶
Prt Sc	Scr Lk	1 ↵	2 ↓	3 ⇅	-	◀▶
Pause	Ins	0 Ins	. Del	Enter ↵	+	⊘

F7	F8	F9	F10	F11	F12
& 7	* 8	(9) 0	{ [}]
Y	U	I	O	P	~ #
H	J	K	L	: ;	@ ' ,
N	M	< ,	> .	? /	↑
+ =	Alt Gr	⌘	Ctrl		

Maltron Qwerty Caps Num Scroll



Win/PC
English UK

L90

Qwerty