



F1	F2	F3	F4	F5	F6
!	@	#	\$	%	^
1	2	3	4	5	6
~ `	Q q	P w	Y e	C r	B t
K45	A a	N s	I d	S f	F g
↑	< , z	> . x	J c	G v	? / b
	Ctrl	Alt	- _		

Esc	Num Lock	7 ↖	8 ↑	9 ↗	/ /	▲
Caps Lock	=	4 ←	5	6 →	*	◀▶
Prt Sc	Scr Lk	1 ↙	2 ↓	3 ↘	- -	◀▶
Pause	Ins	0 Ins	. Del	Enter ↵	+ +	⏻

F7	F8	F9	F10	F11	F12
&	*	()	{	}
7	8	9	0	[]
V y	M u	U i	Z o	L p	 \
D h	T j	H k	O l	R ;	" '
: ;	W n	K m	< ,	- .	> /
+ =	Alt	Alt	Ctrl		↑

Maltron Qwerty Caps Num Scroll



Win/PC
English US

L90

Maltron

Qwerty