

Esc	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	F13	F14	F15	F16	Hilfe	Entf	Bk Sp
									⏪	⏩	⏹	⏴	Prt Sc	Scr Lk	Pause		Einf	⌫	←

°	“	! ¬	”	§ #	\$ £	% fi	& ^	⌘	
^	„	1 i	2 “	3 ¶	4 ¢	5 [6]		
K56	K29	Q	W	E €	R	T			
		q	w	e y	r	t			
⌈	> ≥	A	S	D	F	G			
	< ≤	a	s	d	f	g			
↑	Y	X	C	V	B	;			
	ö	-	j	g	,				
	Ctrl	⌘	⌘	Fn					
		Alt							

Clear	=	/	*
Num Lk			
7	8	9	-
↶	↑	↷	
4	5	6	+
←		→	
1	2	3	⌘
↘	↓	↙	
0		.	
Ins		Del	↵

←	/ \	(~)	· = -	? ·	°	K14
→	7	8 {	9 }	0 ≠	β ÷	'
↑	Z	U	I	O	P	Ü
	v	m	u	z	l	*
	H	J	K	L @	Ö œ	Ä æ
	d	t	h	o	r	~
	N :	M μ ;	:	-	↑	#
	.	w ,	k .	-	x	
	Fn	⌘	⌘	⌘	Ctrl	
		Alt	Gr			

§	Fn	C	N	S
⌘	⌘	⌘	⌘	⌘

Mac
German

Qwertz
Maltron